

Uniwand / Ultra Wand Details and Operating Instructions



Uniwand Ultra Wand for Venetian Blinds With Child Safety Cleats

This control mechanism is available at additional cost. It gives a neat single wand-control for lifting, lowering, and tilting the blind. It can be located on the left or right. It is made from with transparent acrylic. It eliminates the need for free hanging cords.

If you want to lower your blind, pull the acrylic wand down and the blind will lower. **Please hold the cleat at the same time to prevent the blind from lowering sharply and quickly.**

To pull the slats up, pull the cords to the desired position.

The slats can be opened and closed by turning the wand either to the left or right to the desired position.

These uniwands are only available on 16mm and 25mm blinds only.

NB These are available with an additional cost.